

Truck Weekly-Monthly Check Form Explanations

| Weekly Checks | |
|----------------------------------|--|
| Aerial Ladder | exercise ladder/nozzle , proper operation of all controls/gauges/overrides/lights/electrical outlet/breathing air system |
| Air Cleaner | physical damage, obstructed |
| Air Tanks | physical damage, audible leaks, drain water from tanks |
| Batteries | physical damage, cells full, eye green, cable connectors secure, corrosion |
| Breathing Air Tank (Aerial) | physical damage, tank at 3000psi, bleed air |
| Clean Engine/Undercarriage | pressure wash engine compartment/axles/ readily accessible undercarriage |
| Cooling Fan | physical damage, loose fasteners/bearings |
| Drive Belts | physical damage, proper tension |
| Electrically Powered Equip/Tools | physical damage, exercise, proper operation |
| Engine Compartment | physical damage, air/fluid leaks, loose fasteners |
| Generator Operation | proper operation of generator/outlets/lights |
| Hoses | physical damage, leaks |
| Hydraulic Equipment/Tools | physical damage, oil level, exercise, proper operation |
| Knox Key Device | assure that key will release and relock |
| Power Steering Fluid | reservoir full, look for leaks |
| PPV/Saws | exercise, proper operation |
| PTO | proper operation |
| Pump Test | perform per written pump test procedure |
| Undercarriage/Suspension | physical damage, air/fluid leaks, visibly loose fasteners/broken spring leaves |
| Windshield Wiper/Washer | reservoir full, wipers/washers operational |
| Monthly Checks | |
| Intake Relief Valves | exercise, proper operation |
| Ground Ladders | clean and wax |
| Pump Transmission | proper oil level at sight glass |